

UltraLITE



***Please Note:** UltraLITE™ warning bars ordered separately. For detailed product information please see Interior & Exterior bars on pages 21 - 22 and Windshield Lights on pages 59 - 60.

Visor Mount for Ford Crown Victoria
(pair) - #PUL3MØ1



Visor Mount for Chevrolet Tahoe
(pair) - #PUL3MØ2



Visor Mount for Chevrolet Impala
(pair) - #PUL3MØ3



Visor Mount for Dodge Charger
(single brkt.) - #PUL3MØ4



Headliner Mount for Dodge Durango
(pair) - #PUL3MØ5



Dash Mount for Dodge Charger
(pair) - #PUL3MØ6



Rear Deck Mount for Dodge Charger
(pair) - #PUL3MØ7



Center Mount for Ford Crown Victoria
(pair) - #PUL3MØ8



Windshield Shroud
2 Module - #PUL3WS2
4 Module - #PUL3WS5



(4 module length shown)

Universal Bracket, 1 hole:
(pair) - #PUL3DGMØ1



Universal Bracket, 2 hole:
(pair) - #PUL3DGMØ2



Universal Bracket, 3 hole:
(pair) - #PUL3DGMØ3



Universal Bracket, 7 hole:
(pair) - #PUL3DGM



Exterior Replacement Modules:

- Amber #PUL3MØ5AMB
- Blue #PUL3MØ5BLU
- Green #PUL3MØ5GRN
- Red #PUL3MØ5RED
- White #PUL3MØ5WHT

See webpage or price guide for additional replacement parts.

Interior Replacement Modules:

- Amber #PUL3M16AMB
- Blue #PUL3M16BLU
- Green #PUL3M16GRN
- Red #PUL3M16RED
- White #PUL3M16WHT

See webpage or price guide for additional replacement parts.